

# Supplement

|                |                               |                   |          |
|----------------|-------------------------------|-------------------|----------|
| Manual Title:  | i6000s Flex Instruction Sheet |                   |          |
| Part Number:   | 2842359                       | Supplement Issue: | <b>2</b> |
| Print Date:    | June 2007                     | Issue Date:       | 8/19     |
| Revision/Date: | 1, 4/17                       | Page Count:       | 1        |

---

---

This supplement contains information necessary to ensure the accuracy of the above manual.

## Change #1, 451, 598

Under the **General Characteristics** section, replace Operating Temperature and Storage Temperature with:

Operating Temperature: -20 °C to +50 °C

Storage Temperature: -20 °C to +60 °C (without batteries)

## Change #2, 744

On the 3rd page, replace the Position sensitivity and add the figure and the text:

Position sensitivity From 1 % up to 3 % of range with cable, depending on distance from the center (see diagram below). Measurements closer than 25 mm from the coupling are typically greater than 3 % of range.

External Wire influence: 1 % (-40 db) of external current >200 mm from head.

