

# Manual Supplement

Manual Title: TiR2, TiR3, TiR4, Ti40, Ti45, Ti50, Ti55 Users

Print Date: January 2007

Supplement Issue: **2**

Revision/Date: 2, 5/09

Issue Date: 2/11

Page Count: 1

---

---

This supplement contains information necessary to ensure the accuracy of the above manual. This manual is distributed as an electronic manual on the following CD-ROM:

CD Title: TiR2, TiR3, TiR4, Ti40, Ti45, Ti50, Ti55

CD Rev. & Date: 2, 6/2009

CD PN: 2808421

## Change #1,

On page 3-1, following **Scan Target** add:

### *Note*

*All thermal imagers require appropriate warm-up time in order to obtain the most accurate temperature measurement and best image quality. This time can often vary by model and by environmental conditions. Although most imagers are fully warmed-up within 3-5 minutes, it is always a best practice to wait at least 10 minutes if the most accurate temperature measurement is critical to your application. Whenever changing or adding optional lenses, additional stabilization time may be required depending on the situation.*