


# Testing production line equipment with Fluke Connect™ wireless tools

FLUKE®



1

## Identify and diagnose problems quickly and confidently

See motor input and output readings simultaneously on the Fluke Connect™ app

2

## Get historical data in the field, where and when you need it

Thermally inspect bearings, gearbox and couplings and compare to previous images saved in EquipmentLog™

3

## Share results without writing anything down

AutoRecord™ the new data to Fluke Cloud™ storage for the entire team to reference



FLUKE  
CONNECT™

SEE IT.  
SAVE IT.  
SHARE IT.

