

9040 Phase Rotation Indicator



Technical Data

Features

- Large display to easily determine field rotation
- Indication for all three phases
- CAT III 600 V
- Included accessories: test leads and probes, alligator clips
- 2-Year Warranty

Phase Rotation Indicator for industrial applications

The Fluke 9040 Phase Rotation Indicator is a portable handheld instrument designed to detect the rotary field of three-phase systems. With three test leads, this rugged tester easily determines a clockwise or counterclockwise direction.

Specifications

Environmental

Operating temperature:
0 °C to +40 °C (32 °F to 104 °F)

Pollution degree: 2

Type of protection: IP 40

Mechanical specifications

Size (HxWxD):

124 mm x 61 mm x 27 mm
(4.9 in x 2.4 in x 1.1 in)

Weight: 200 g (0.44 lbs)

Safety specifications

Electrical safety:

IEC 61010/EN 61010,
IEC 61557-7/EN 61557-7

Maximum operating voltage (U_{me}): 690 V

Protection levels: CAT III 600 V to ground



Electrical specifications

Power supply: From unit under test

Determine rotary field direction

Nominal voltage: 40 to 690 V ac

Frequency range (f_n): 15 to 400 Hz

Current Pickup: 1 mA

Nominal test current (in per phase): 1 mA

Warranty: 2 years

Included

3 self-retaining test probes (black)

Alligator Clip

Users Manual

Ordering Information

Fluke-9040 Phase rotation
indicator

Fluke. Keeping your world
up and running.

Fluke Corporation

PO Box 9090, Everett, WA USA 98206

Fluke Europe B.V.

PO Box 1186, 5602 BD

Eindhoven, The Netherlands

For more information call:

In the U.S.A. (800) 443-5853 or

Fax (425) 446-5116

In Europe/M-East/Africa (31 40) 2 675 200 or

Fax (31 40) 2 675 222

In Canada (800) 36-FLUKE or

Fax (905) 890-6866

From other countries +1 (425) 446-5500 or

Fax +1 (425) 446-5116

Web access: <http://www.fluke.com/>